


BORE GAUGE CHECKER



- Used together with gauge blocks to set bore gauges

Code	Setting range
2395-400	18-400mm



Unit: mm

